

SPECIFICATIONS

MOULDING # RA108

CUSTOMER: _____

COMMENTS: 20* HOOK

NOTES: USE 3/4 BULLNOSE KNIVES
ON SIDE. APPLY DRIP KERF ON TABLESAW

5/16 T1 CORR., 10MM AXIALS, 1.375 START DEPTH
COPING: 7/8"- 1" WIDE, 1.25 START DEPTH, BEVEL FOR TENON, 20° HOOK, 2 HEAD ON 1 SHAFT

INSIDE OF MACHINE

